

WARNING

Never place your stove, campfire, or other flame source in or near your tent. Never smoke, cook, light, or refuel a stove or any other heat source inside your tent. Death or injury by suffocation, exposure to high concentrations of carbon monoxide and / or serious burns is possible.

Maintain adequate ventilation inside your tent at all times. Death or injury by suffocation is possible. Anchor your tent properly at all times to reduce the risk of loss or injury to the tent or occupants.

When using tent poles (i.e. set-up, break-down), be aware of any / all surroundings in order to reduce the risk of injury to yourself or others.

Consider the possibility of vehicles, falling rocks or tree limbs, lightning strikes, flash floods, avalanches, strong winds, and other hazards when choosing a pitch site to reduce the risk of loss or injury.

Tent meets the CPAI-84 standard for flame retardancy.

If you have additional questions, please contact LiteFighter Systems at 678.319.0051



LITEFIGHTER®

www.litefighter.com

©2013 LITEFIGHTER SYSTEMS, LLC





LITEFIGHTER®

SCOUT 1

SET-UP GUIDE

DIMENSIONS



VESTIBULE AREA = 10.5ft²

CONTENTS




1.) Stuff Sack




2.) Body



3.) Rainfly




4.) Pole-Set & Bag



5.) Stake Bag & Accessories (Repair-Patches (2), Stakes (6), Repair Tube (1), Guy-Lines (4))

SET-UP GUIDE

SCOUT 1




**Shelter Set-Up
(Ground)**


**Note: Site Selection: Prior to set-up, ensure area is clear of any and all loose vegetation and sharp objects (i.e. sticks, rocks, etc.).*




1. Lay out the shelter with assembled poles on top
2. Snap pole ends to four corners of shelter.
3. Connect the clear cap clips (2) located at the top of shelter to the cross pole.
4. Connect the shelter clips to the pole (12).




**Attaching Rainfly
(Ground)**




1. Connect the plastic clips (2) located under the rainfly to the cross pole
2. Attach Velcro tabs (4) under the rainfly to the poles.
3. Attach the rainfly corner hooks (4) (Fig. A). Adjust webbing to desired tension (Fig. B)
4. Stake out shelter. Locate cordage loops (Fig. A) on rainfly (2 front and 1 back) and attach to stakes. Adjust tension by pulling the cord ends (Fig. B).




**Shelter Set-Up
(Cot)**



1. Layout shelter and poles on cot.



2. Wrap hook around cot leg (5) and snap on to locking bar (Fig. A). Open cam buckle and adjust webbing to desired tension (Fig. B). Close cam buckle to lock in place (Fig. C)
3. Follow steps 2 - 4 "Shelter Set-Up" (Ground)



**Attaching Rainfly
(Cot)**

Follow steps for "Attaching Rainfly" (Ground)



WARRANTY: LiteFighter Systems takes pride in its workmanship and undertakes to manufacture the best possible products. Therefore, we warranty all LiteFighter Systems products against defects in materials or workmanship for 12 months after date of delivery. Since no LiteFighter Systems product is indestructible, it does not cover defects attributable to or resulting from normal wear and tear, natural hazard damage (ie: weather, animals), accidents, abuse, alterations, misuse, improper care, or if the product is used for a purpose for which it is not intended.